



Instant. Precise. Portable.  
Flexible radiation monitoring for your office.

# Getting Started with instadose



**WARNING! DO NOT connect any instadose device to your computer until after you have installed the instadose driver.** The driver will be downloaded during the registration process.

Select your user type from the descriptions below and follow the instructions supplied.

**Administrator-** You bought the device(s) for your own use or will be giving them to employees.

**Wearer Account Activation** - You received a device to wear with a username and temporary password assigned.

Launch your internet browser and enter the following web address:  
[www.instadose.com](http://www.instadose.com).

## Administrator

### Step 1: Install Driver

- [Click] "MY ACCOUNT LOGIN" and login with the username and password that you created when you purchased the device(s).
- On your homepage [click] " You have uninitialized device(s)".

■ [Click] "Download Driver". [Click] "Run" to begin the file download process. A security warning message will open. [Click] "Run" to begin the installation wizard. Follow the prompts to install the instadose driver to your computer. Once installed [click] "Continue" to proceed to the initialization step.

### Step 2: Initialize Device(s)

■ Connect your first device to the USB port and [click] "Initialize Device(s)". Once the device has been successfully initialized remove the device and repeat this step for each device until all devices have been initialized.

■ When you have initialized all devices, [click] "Continue" to proceed to Step 3.

### Step 3: Add Locations

■ A list of locations for your account will be shown. If you do not need to create a new location, please [click] on the default location listed and then [click] "Continue".

#### Need to create new locations?

You can add locations to manage devices for offices in other regions. If you would like to add a new location to your account, please [click] "Add A New Location" and follow the prompts. Once complete [click] "Continue" to proceed to Step 4.

### Step 4: Assign Devices

■ **To Yourself-** To assign a device to yourself, from the wearer column [click] "Unassigned" and select your name from the list.

[Click] "Finish Device Registration" to proceed to the Registration Complete page where you can print a copy for your records.

■ To identify your device, a small white label has been provided inside the instadose box. Place the label in the square indent on the back of the device.

■ **To an Employee-** To assign a device to an employee [click] "Add A New Wearer", complete the required information and [click] Save and then [click] either "Save" or "Save & add another". The table will refresh with the wearer listed next to the device assigned. Once you are finished assigning device(s), [click] "Finish Device Registration" to proceed to the Registration Complete page where you can print a record of all devices assigned.

■ Provide the username and temporary password to each new wearer for them to activate their AMP account.

**NOTE:** If you would like to reassign a device from the table [click] on the wearer you would like to change and use the pull down to select a different wearer. To unassign a device select "Unassigned" from the pull down.

## Wearer Account Activation

**DO NOT connect the device to your computer until you install the instadose driver onto your system.**



■ [Click] "MY ACCOUNT LOGIN" and login with the username and temporary password provided to you. You will be prompted for a new password and security question. Upon completion [click] "Continue", and you will see a confirmation screen [click] "Proceed" to be directed to your homepage.

■ If the "Download the driver" message appears on your homepage you must install the driver on the system. [Click] "download driver", then [click] "Run" to begin the file download process. A security warning message will open. [Click] "Run" to begin the installation wizard. Follow the prompts to install the instadose driver to your computer.

## Perform Readings

■ Once your device has been initialized and the driver installed, you can plug in your device and get your dose reading by logging into your account.

■ Login to your account and [click] "Plug in your instadose device now and [click here](#) to get an instant reading". Your current dose level will be displayed in mrem. You can also view your cumulative dose by [clicking] "Cumulative Dose To Date".

■ If you are the Administrator, you can perform readings for devices in your account. [Click] "Perform Reading" and follow the

directions listed on the screen. Under the “Report” tab you can run and view reports for your account.

*NOTE: If you perform a reading right after registration your current and cumulative dose levels will be 0. The proprietary algorithm used by instadose subtracts background radiation based on your state of residence. If you have sent your previous lifetime dose history to Quantum Products, your lifetime dose level will be reflected on the Annual Radiation Report.*

## Reports

The following reports are available through AMP under the Reports tab:

- Radiation Exposure Summary Report
- History Detail Report
- Device Not Read (*not available to wearers in an account*)

## Wear & Care of Your instadose device

**Wear-** The instadose device should be worn on the front of the torso. Devices are commonly clipped to clothing at waist or chest level.

**Care-** Do not store instadose devices next to radiation sources. Devices should not be worn outside the workplace, or during personal medical procedures. Companies that collect all devices at the end of each shift and store them in a central location away from radiation sources can avoid having to replace dosimeters which are accidentally lost.

## Troubleshooting

Q. What if I forgot my password?

A. Under the AMP MY ACCOUNT LOGIN [click] “Forgot User name or Password”. We’ll send a temporary password to the e-mail address in your profile right away.

Q. What if my device does not work?

A. You have either not installed the driver on your system or not activated the device. To install the driver login to your account and [click] “download driver” from your homepage.

To activate your device you must complete the registration process. During the registration process you will install the instadose driver on your computer and initialize your device. To begin the process login to your account at: [www.instadose.com](http://www.instadose.com). From your homepage [click] “You have uninitialized device(s)” and follow the prompts.

Q. How do I contact technical support?

A. Our technical support representatives are ready to assist you in any situation. Our team of health physics experts are also available to answer questions or for consultation. Simply call in the U.S. /Canada: 800.359.9686, or you can submit your question using the Technical Support form.

You can find additional information in the FAQ tab within the Knowledge Center at [www.instadose.com](http://www.instadose.com).

instadose™  
BY QUANTUM PRODUCTS

P.O. Box 16451 ° Irvine, CA 92623  
Phone: 800.359.9686 ° Fax: (949) 296-1142  
[www.instadose.com](http://www.instadose.com)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.